Please order by parts number,not key number
*Bitte,Best:-Nr.angeben(Nicht " key " -nr.)*
Veuillez indiquer le numero de la piece(Non " key " no.)

WARRANTY QUALITY

# SPINNING REEL SCEPTER

## GX2000 / 3000 / 4000 / 5000
## 6000 / 8000 / 9000 / 10000

GEAR RATIO ( 5.2 / 4.1 )




| Key NO. | Parts No. | Parts name |
|---|---|---|
| 1 | 2YD-036-05 | DRAG KNOB ASSEMBLY |
| 2 | 2E4-013-01 | DRAG WASHER RETAINER |
| 3 | 2W1-092-01 | 060-210 WASHER |
| 4 | 2F3-032-01 | DRAG KNOB CLICK NUT |
| 5 | 2W1-094-01 | 060-220 WASHER |
| 6 | 2W3-013-01 | EARED WASHER |
| 7 | 2W2-033-01 | KEY WASHER |
| 8 | 2YT-195-07 | SPOOL TOTAL ASSEMBLY |
| 9 | 2W2-041-01 | KEY WASHER |
| 10 | 2C1-103-01 | MAIN SHAFT BUSH |
| 11 | 2W1-115-01 | 061-160 WASHER |
| 12 | 2L3-018-01 | CLICK LEAF SPRING |
| 13 | 2F8-027-02 | CLICK LEAF SPRING HOLDER |
| 14 | 2W2-034-01 | KEY WASHER |
| 15 | 2E1-055-01 | A26-100 SCREW |
| 16 | 2YF-052-01 | RETAINER ASSEMBLY |
| 17 | 2Z1-006-05 | 613-3.5 BALL BEARING |
| 18 | 2M3-121-01 | MAIN SHAFT |
| 19 | 2E3-026-01 | ROTOR NUT |
| 20 | 2YR-050-05 | ROTOR ASSEMBLY |
| 21 | 2A4-034-01 | ONE-WAY CLUTCH INNER TUBE |
| 22 | 2E2-029-01 | B26M-060 SCREW |
| 23 | 2F5-196-01 | ROLLER CLUTCH RETAINER |
| 24 | 2Q1-071-01 | CAGE SPRING |
| 25 | 2YZ-015-01 | ONE-WAY CLUTCH BEARING ASSEMBLY |
| 26 | 2E2-014-02 | F26M-060 SCREW |
| 27 | 2F5-178-01 | BEARING RETAINER |
| 28 | 2Z1-008-05 | 1020-5 BALL BEARING |
| 29 | 2G2-061-01 | PINION GEAR |
| 30 | 2YB-207-01 | BODY ASSEMBLY |
| 31 | 2F5-336-01 | REAR COVER |
| 32 | 2E2-005-03 | B26M-080 SCREW |
| 33 | 2R5-075-01 | BAIL TRIP LEVER A |
| 34 | 2R4-090-06 | BAIL TRIP COVER |
| 35 | 2E1-016-02 | B26-080 SCREW |
| 36 | 2Q3-042-01 | BAIL TRIP LEVER SPING |
| 37 | 2R5-074-01 | BAIL TRIP LEVER B |
| 38 | 2E1-025-01 | b30-080 SCREW |
| 39 | 2F8-084-01 | CAGE |
| 40 | 2Z3-003-01 | ROLLER |
| 41 | 2A3-009-01 | ANTI-REVERSE RATCHET |
| 42 | 2F2-035-01 | ANTI-REVERSE PAWL |
| 43 | 2H6-002-10 | HANDLE SCREW CAP |
| 44 | 2C3-047-01 | HANDLE SCREW SLEEVE |
| 45 | 2B2-092-01 | BODY COVER ( R ) |
| 46 | 2Z1-035-05 | 917-5 BALL BEARING |

| Key NO. | Parts No. | Parts name |
|---|---|---|
| 47 | 2G3-082-01 | DRIVE PINION |
| 48 | 2G3-064-01 | OSCILLATING GEAR |
| 49 | 2M2-011-01 | OSCILLATING CAM |
| 50 | 2W5-062-01 | COVER |
| 51 | 2E1-063-01 | F26-070 SCREW |
| 52 | 2E2-011-02 | F30M-080 SCREW |
| 53 | 2C1-089-01 | COLLAR |
| 54 | 2M1-058-01 | OSCILLATING SILDER |
| 55 | 2E5-052-01 | OSCILLATING SLIDER RETAINER |
| 56 | 2E1-014-01 | B40-100 SCREW |
| 57 | 2E2-007-01 | B30M-100 SCREW |
| 58 | 2R2-050-01 | BAIL ARM |
| 59 | 2C1-049-01 | LINE ROLLER COLLAR |
| 60 | 2Z1-001-05 | 508-2.5 BALL BEARING |
| 61 | 2R6-014-01 | LINE ROLLER |
| 62 | 2C1-068-01 | COLLAR |
| 63 | 2YL-134-01 | BAIL ASSEMBLY |
| 64 | 2R4-089-05 | BAIL SPRING COVER |
| 65 | 2R5-040-01 | BAIL TRIP SHAFT |
| 66 | 2W1-044-01 | 016-035 WASHER |
| 67 | 2Q1-024-01 | BAIL SPRING |
| 68 | 2Q3-009-01 | ANTI-REVERSE SPRING |
| 69 | 2A2-071-01 | ANTI-REVERSE CAM |
| 70 | 2G1-123-01 | DRIVE GEAR |
| 71 | 2W1-014-03 | 091-130 WASHER |
| 72 | 2B2-093-01 | BODY COVER ( L ) |
| 73 | 2E1-006-02 | A30-130 SCREW |
| 74 | 2YH-249-03 | HANDLE TOTAL ASSEMBLY |
| GX2000 | SPECIAL PARTS | |
| 8 | 2YT-192-05 | SPOOL TOTAL ASSEMBLY |
| GX3000 | SPECIAL PARTS | |
| 8 | 2YT-193-05 | SPOOL TOTAL ASSEMBLY |
| GX4000 | SPECIAL PARTS | |
| 8 | 2YT-194-05 | SPOOL TOTAL ASSEMBLY |
| GX6000 | SPECIAL PARTS | |
| 8 | 2YT-196-07 | SPOOL TOTAL ASSEMBLY |
| GX8000 | SPECIAL PARTS | |
| 8 | 2YT-197-07 | SPOOL TOTAL ASSEMBLY |
| GX9000 | SPECIAL PARTS | |
| 8 | 2YT-198-07 | SPOOL TOTAL ASSEMBLY |
| GX10000 | SPECIAL PARTS | |
| 8 | 2YT-199-07 | SPOOL TOTAL ASSEMBLY |
| GEAR RATIO 5.2 | SPECIAL PARTS | |
| 29 | 2G2-045-01 | PINION GEAR |
| 34 | 2R4-090-05 | BAIL TRIP COVER |
| 70 | 2G1-124-01 | DRIVE GEAR |